

# ALL-WEATHER INTERIOR LINER INSTRUCTIONS

## ⚠️ WARNING:

- These All-Weather Interior Liners are designed to fit only the intended vehicle application model(s) and year(s) as sold. Do not use in any other make, model or year of vehicle.
- After installing the All-Weather Interior Liners and before starting the vehicle, check the operation of the accelerator pedal and brake pedal to ensure that the All-Weather Interior Liners do not interfere with their movement through their full range of motion. Before starting the vehicle and every time before use, ensure that the All-Weather Interior Liners do not interfere with the accelerator or brake.

## When installing these All-Weather Interior Liners:


- The product is made of environmentally friendly TPE. If there is a slight odor when you open the packaging, please do not worry. The odor is non-toxic and harmless. Simply place it in a well-ventilated area for 12 hours and the odor will disappear, or you can rinse it with water and let it dry.
- Due to long-distance transportation or packing compression, the floor liners may be slightly wrinkled. The following ways can help you recover them smoothly:
  - ▲ Lay them flat and wait for natural recovery, or place a heavy object on them for 24 to 48 hours to restore.
  - ▲ When the temperature is low, recovery will be more difficult, you can use equipment such as electric hair dryer to help recovery, or use hot water to help recovery.
- It is imperative to remove any existing carpet mat or other floor mats prior to installing these all-weather interior liners. Don't place on top of any other floor mats.
- Do not mix up the sides. Install the driver's side All-Weather Interior Liner on the driver's side floor area. Install the passenger's side All-Weather Interior Liner on the passenger's side floor area.
- Make sure that the All-Weather Interior Liners fit the contours of the vehicle floor space. Move the two front seats to the last position so that the floor liner is in line with the car floor shape and lock the clips to the floor with the holes in the floor liner in the corresponding position.
- Install the All-Weather Interior Liners right side up, not upside down.
- Position All-Weather Interior Liner carefully. Ensure that there is no interference with vehicle controls.

## Notice:

If you find they do not fit perfectly, please reconfirm the order matches your car.

- \* Whether you chose the correct year for floor liners;
- \* Whether it has different configurations;
- \* Whether there is a distinction between gasoline and hybrid cars;

Align the floor mat holes with the corresponding clip positions on the floor.



(The above images are for reference only and may not represent the actual vehicle model)

IF YOU NEED MORE HELP, PLEASE CONTACT OUR CUSTOMER SUPPORT TEAM